

REMS Macho

Teileverzeichnis

Aktueller Stand
siehe www.rems.de

Spare parts list


Latest version
see www.rems.de

Liste des pièces

Situation actuelle
voir www.rems.de

Elenco dei pezzi

Ultimo aggiornamento
vedi www.rems.de



deu	eng	fra	ita	
— Brennerrohr mont. Pos. 1, 2 und 4	Burn tube assembly Pos. 1, 2 and 4	Tube brûleur assemblé Pos. 1, 2 et 4	Tubo bruciatore montato Pos. 1, 2 e 4	160108RA
2 Schrumpfschlauch	Heat-shrinkable sleeve	Tube flexible contractible	Tubo flessibile a contrazione	160115
— Düsenträger mont. Pos. 3, 6 und 7	Orifice assembly Pos. 3, 6 and 7	Porte tuyère Pos. 3, 6 et 7	Porta ugello montato Pos. 3, 6 e 7	160129RA
4 Funkengenerator	Ignitor	Générateur des étincelles	Generatore di scintilla	160112R
5 Zentrierbüchse	Centering bush	Douille de centrage	Boccola di centraggio	160138
6 O-Ring	O-Ring	Joint torique	Guarnizione O-Ring	060175
8 Kerbschraube	Sheet metal screw	Vis à tôle	Vite autofilettante	083111
9 Griffschale 2	Handle shell 2	Coquille poignée 2	Calotta impugnatura 2	163102R-G
10 Ventilblock kompl. mit Gasanschluß	Valve block complete with gas connect.	Bloque soupape compl. à raccorde + gaz	Blocco valvola compl. con attacco gas	160118R
14 Griffschale 1	Handle shell 1	Coquille poignée 1	Calotta impugnatura 1	163101R-G
— Überwurfmutter mit Tülle Pos. 16 und 17	Hollow cap nut with socket Pos. 16 and 17	Ecrou six pans et passe-cable Pos. 16 et 17	Dado cavo con boccola Pos. 16 e 17	160153